

Derek Marshall Lighting LLC

Wave chandelier mounting Instructions

Do not exceed the lamp wattage of 100 watts per bulb

Consult a qualified electrician to ensure correct branch circuit conductor. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and hazards involved.

Note: The important safeguards and instructions appearing on this page are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors which cannot be built into any product. These factors must be supplied by those installing and operating this fixture.

1. Remove all materials from packing and set on a non-scratch level surface. Please handle the armature assembly with care. Avoid dropping, bumping or scratching. The necessary hardware is in an included package which includes the canopy cover, fixture bracket, mounting plastic lock rings and lock washers. Please take care to avoid scratching the metal finish on the armature and drop tubes.
2. Shut off power to the electrical box at the circuit breaker. Attach the provided fixture bracket to the ceiling box by means of two 8-32 screws. Ensure the two provided screws in the fixture bracket extend at least an inch beyond the bracket (the final adjustment will come when the ceiling canopy is attached).
3. Attach the drop tube to the central cluster body of the armature. **Make sure that the flexible swivel (hang-straight) is at the top of the drop tube assembly where it attaches to the ceiling canopy.** If a two piece drop tube is used, carefully screw the two pieces together tightly before attaching to the ceiling canopy.
4. Thread the black and white supply wires coming from the cluster body through the ceiling drop tube assembly and screw the drop tube assembly onto the cluster body tightly by hand using the provided lock washer. Make sure the small plastic grommets inside on each end of the drop tube remain in place. **Ensure that the swivel mount is at the top of the drop tube and attaches to the ceiling box by way of the canopy.**
5. Attach canopy cover to the swivel on the end of the drop tube using the lock washer and nut provided. Tighten securely with a 9/16" wrench.



Derek Marshall Lighting
85 Upper Rd., Sandwich NH 03227
Tel: 603-284-7000

Derek Marshall Lighting LLC

6. Holding the armature, drop tube and canopy assembly, attach the fixture wires to the supply wires using appropriate wire nuts ensuring black goes to black and white to white. This is best done with an assistant. (Wire nuts are usually supplied by the electrician who installed the box. If you need additional wire nuts, please contact us.)
7. Slide canopy up and onto the mounting screws protruding from the fixture bracket. Apply the two acorn nuts and tighten until the canopy is snug against the ceiling. Please ensure that the excess electrical wires are safely pushed back into the box before tightening. Make sure the hang-straight allows for some movement of the drop tube.
8. Slip each of the glass lens assemblies onto the threaded bulb holder and screw on the shade rings to attach the glass lens assembly. Be sure the ring is correctly holding the glass element.
9. Installation is now complete. Install bulbs, turn on the power.



If you have any questions on this procedure, call us at 603-284-7000

Derek Marshall Lighting
85 Upper Rd., Sandwich NH 03227
Tel: 603-284-7000